
EasyShipDesign

• Overview



The EasyShipDesign(ESD) it is a ship design system developed to create a single 3D model ship database.

The information in the Ship Database Model contains all the technical data that is needed to define the final product. It addresses all phases in the design and production process. Information from one stage can be used in the next stage. All types of drawings, parts and reports can be derived from the model.

Comparing with the existing design system from the market the EasyShipDesign offer some new and unique feature like : full integration , one single application for everything , one single database , a fully integrated nesting system , objects topology , standard contour definitions defined by user , easy to learn because the working style is like common application like AutoCad.

The purpose of this document is to present and explain the EasyShipDesign concept and to give a general overview of the EasyShipDesign shipbuilding system. The document covers the main application functions, features and concepts in ESD, but for the purpose of clarity, explanations have been simplified.


The application have a lot state of art tools which make possible the next features:

- Tools for hull lines manipulation and intersection
- Tools for surface creation, manipulation and intersection
- ✓ Tools for standard parametric contours
- ✓ Tools for plane panel creation and manipulation 2D/3D
- Tools for curved panel creation and manipulation 2D/3D


- Tools for automatically parts position number
- ✓ Tools for automatically drawing section creation
- Tools for automatically parts list creation
- **V** Tools for pipes , cable trays and HVACs creation
- ✓ Tools for structures
- ✓ Tools for outfitting components creation
- ✓ Tools for view / scene manipulation
- Tools for production information, plate parts , profile parts , templates, profiles sketches , inverse bending line , pipe spools, pipes isometrics, parts list reports
- Tools for databank maintenance, databank objects manipulation
- ✓ Tools for dxf,step,acis,x3d,stl input/output interface 2D/3D.
- ✓ Tools for 2D drafting like AutoCad
- ✓ Tools for assembly model and assembly drawings, welds detection
- ✓ Customizable drawing forms ; reports in Excel csv file format


All that operations are made in interactive mode and the application checks the user action.

The application working sketch




• Screenshots







Tug side view shade rendering



Camera side view motor yacht 36m with transparent shell plates




Camera view from inside motor yacht 36m with transparent shell plates




Camera view motor yacht 36m with transparent shell plates

Copyright©2002-2018 SoftCAD Solutions



Stiffener 3D modeling example



2D section modeling (plane panels)

	y Ship I							Easy Sh	hip Design	n : <2005-PATROL>									
See N Lob D Police M Hats A Strate P Organize K + Trie D Precesse C Grond SM Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Precesse M Expersent DK Active extens P Date A Strate P Organize M Control SM P Organize M Organize M Control SM P Organize M Organize M Organize	Home	2D Window 3D Window																	
B NOLTING Ned text O Orde A Synd Y Deck A Nodely Deck A Nodely	i 🗳	Open 🖻	Copy 🦯	Line 🥻	•	Arc A	Text 💾	Quick		Move 🔛	Distance	/// Plane	panel 🔊	Structure	< Cabl	e line 🔚	Drawing form	+	Move po
Pé Edit Des 1 Des 2 Arrotations Dimensions Modify Malding 1 Modify 2 Modify 3 Section view 1 Section view 1 <td></td> <td>Save 🖙</td> <td>Undo 🚅</td> <td>Polyline</td> <td>😫 На</td> <td>itch 🕰</td> <td>Edit text 📕</td> <td>Change text</td> <td>4.</td> <td>Trim 🔡</td> <td>Properties</td> <td>🖅 Curved</td> <td>panel 🔀</td> <td>Pipe line</td> <td>e Equip</td> <td>ment 🗖</td> <td>Active section</td> <td>P</td> <td>Draw po</td>		Save 🖙	Undo 🚅	Polyline	😫 На	itch 🕰	Edit text 📕	Change text	4.	Trim 🔡	Properties	🖅 Curved	panel 🔀	Pipe line	e Equip	ment 🗖	Active section	P	Draw po
<pre>c c dru c n v m v m v v v v v v v v v v v v v v v</pre>	F	_In/Out files 📆	Find text 🕑	Cirde 🤇	Div	ride 🔬	Symbol	Style	>	Color 🖊	Direction	В	racket 🕜	HVAC line	Section	view 🛃	Remove info	ш	R
Image: Series in the		File	Edit	Draw 1	Draw 2	A	nnotations	Dimensions	1	Modify	Utilities	Modeling 1		Modeling 2	Modeling 3		Section view 1	Sect	tion view 2
R	0		: dr	v on 🗸 📘 Lime	~ 0 ~	continuou	s v								📩 🖏 😋	🕵 🔊	🔍 🗶 R 💡	F ALL	• 🗖 (
R																			
R							6 -			<u> </u>	34								
							France F14	 *		9 9	1 3011								
M M M M M M M M M M M M M M							┍┟╌┟╌╿╼┥╺┥╺┽┯┥			ø		. <u></u>	i i i	1					
d the drawng the contract of the second se						1111	Q 1 1 1 I	11114		P			<u> </u>	न ज					
Image: series of series o						0	2 4	0					- H	-					
d d d d d d d d d d d d d d						▶ ⊳ - ⊳	>	>D D D 					1						
d the drawng the command the						A		- 1				٨	7	2					
d d d d d d d d d d d d d d d d d d d							- Ar with					0		1					
d strong wards						° o					0	0							
d strong wards					۳			i ka internet i negati ka i											
d d d d d d d d d d d d d d d d d d d																			
d dr dr dr dr dr dr dr dr dr dr dr dr dr											uer.	EIN/							
d drag draving be command					4					12									
d d d d d d d d d d d d d d d d d d d													13						
d d d d d d d d d d d d d d d d d d d										[©] ⊑₹		<u>A</u>	ret [©] −						
d drig drwing se command					17		Forme EPA	and and a stand and and stand											
d d d d d d d d d d d d d d d d d d d					- 🔍			Q.		<u> </u>			4	3					
U ed ating farwing secontiants b ESD						2		- Q 18	- 47 - 6	8 4 A		A	<mark>≥</mark> <u>⊾8</u>						
U ted rating farwing sec command ESD						-					and the second second	and a state of the							
U ed gaving secondard																			
U ad atang farwing as command						e 19		₿	8			at the set of the set of the							
U ed rating fawing ose command						0	Contractor Contractor	and a state of the						98					
U ad atang farwing as command																			
U ed and farwing ac command							اهره اه	an 110 21 an an a					- Inge						
rating drawing ose command									56 ^{B.}										
rating drawing ose command										*	·								
rating drawing ose command																			
rating drawing ose command																			
ose command ESD		ter ula e													^				
	rating o ose coi	mmand															ESD		

workshop drawing example (all section are live, are automatically recreated if the model is change)

asy Ship Design : <2005-PATROL> - [Production info]	• •	,	·	- 0
		Easy Ship Design : <2005-PATROL>		
Home 2D Window 3D Window				
🕼 Select project 🕼 About 🗅 New window 🖉 hange		🛞 Hull prod info 🦵 2D standards	Syncronise main databank	
📾 Working module 📓 Log file 🚍 Switch windows 💌 Sho				
🕼 New project 🍲 Settings 🔁 Cascade 🟪 Add a		🗧 🌾 Edit production info 📅 🛛 Components		
	ibanks 1 Databanks 2 Inquiry	Production Info Standards	Network	
0 : drw on \checkmark Red \checkmark	0 v continuous v		<u> </u>) 🔍 🕅 🗑 F ALL 0 🗖 🖉
R .				
<u> </u>				
	2 E			
the second s				
¥				
		-		
	<u></u>			
	N. Contraction of the second s			
ngl Production information must be updated for : 3(F9396C55-5E1F-4114-8105-035093 ngl Production information must be updated for : 3(F9396C55-5E1F-4114-8105-035093 reating drawing boose command	1466383333.0 1466383333.0			ESD
37114.3178,15598.4278 @40258.5	956<22.7961			

Preview of production 2D model parts (parts are created automatically from 3D model)


🚬 Ea	isy Ship E	Design : <2005-PATRC	L> - [GL2DDrawing_3]												- ć	x v
							Easy Ship	Design : <2005-PATE	OL>							
		2D Window 3D Windo	ow													3
2	2	Open 🗎	Сору 🖍	Line 🧹	Arc A	Text 💾	Quick •		: ==	Distance 📶	Plane panel		Cable line 🚦	Drawing form	Ф м	love posno
~ •		Save 🌇	Undo 🚅	Polyline 🙀	Hatch 🕰	Edit text 💾	Change text) 🖹	Properties 🚭	Curved panel	• · · ·	• · · · ·	Active section	ر م	raw posno
	F	_In/Out files 📆	Find text 📀	Cirde 🕻	Divide 🔬	Symbol	Style	-	1	Direction	Bracket d		Section view	Remove info		Ruler
-		File	Edit	Draw 1	Draw 2	Annotations	Dimensions	Modify		Utilities	Modeling 1	Modeling 2	Modeling 3	Section view 1	Section	
Ð	0		: drw	on 🗸 🗌 Yellow	✓ 0 ✓ continuo	us 🗸							📩 🕅 ct 🕰 🛛	ଷ୍ୟ ହେଳେ ଢ଼ା	FALLO	□ Ø >
				-	_							_				
					14_5E.21 F.4 05201	/ RA 6820 / PA 0	1.01 ×									
						× / / _										
					e MG e	1										
					FORE			-102-2506								
					TORL			-102-2300				Γ				
					_											
					USE BY HEAVE											
					1.06-26 HR 1103-3744 1.075 FR 140302.01											
					ERC J WIRLDHARD THEORY (WARD WIRD RANK) PROTOWING RANKS WARD (2003 2004, 200 2004 2004 2007 200 2004 200	к.ат,				
					PROTOWING RUNN WALSHOLD			BENDING TAI	UF		WALSO, A	e and and a				
								DEMDING TH								
					10 (287.4 - 267.4 - 1677.4 V - 225 - 364 - 37.0	1974 357										
					U: 867.4 967.4 1667.4 V 27.7 38 150 U: 267.8 667.4 757.4 V 8.7 377 383	1167.4 1287.4 1387.4 1467. 45.0 35.8 31.9 22.8 057.8 587.4 2567.8 26.1 3.3 307										
					V 68 972 383 0:2074 404 5074 V 727 384 403											
						26.4 9. 26.7 26.74 76.74 56.7 554 50.6 36.7 133										
					-											
						XTF 072	307			977						
					on Theorem States Strend configuration Sector R		- V1		~	/	Barn 6503/4 Toro accil.07	a 2 20 Augusta -				
					28 AN 112	V C A46 0		- 19 <u>66</u> - 1 <u>6</u>	-	y1	Red come 1					
V				L												
↑																
	20															_
	and > 2D to loading	DXF input file											^			
Finish	ed to load	ding file												ESD		
Choos	se comma	inu														

 645.418, 23.7021


 Profile sketch whit inverse bending curvature table (automatically created from 3D model)

9	📙 🤊 - (°	• •								5	S20_part_	list.csv - Micros	oft Excel				
	Home 1	Insert	Page Layout	Form	nulas	Data Review	v Vie	w D	eveloper								
- F	🖁 🔏 Cut		Calibri	- 11	- A A	===	**	W ra	ap Text		General	*	S		- 📪 📑		AutoSum • A
Past	Copy		BIU.		A - A			Far Me	rge & Cente	er v	\$ - %	• • • • • • • • • •		Format Cell	Insert Delete	Format	Sor
*	Format Pa	ainter G			_				9				-	s Table * Styles *	· ·	- Q	Clear * Filt
	Clipboard	-)(ont		×	Alignn	nent		(w)	Nu	mber 🕞	(St	yles	Cells		Editing
	A41		● f _x	S20													
	А	В		С		D		E	F		G	Н	I	J	К	L	M
	NoduleName					Туре		ide	Material				COG.x	COG.y	COG.z		Splittet statu
	20		-			PLANE PLATE		OVERCL		TH7.0		609.055003	1653.5	0.032692			YES
	20	60	@PAN-FRA	MEFR3-6	5-PLA-18	PLANE PLATE	C	OVERCL	A	TH10	0.00	432.217043	1655	-0.255154			YES
	20	480	@PAN-FRA	MEFR3-6	5-STI-19	PLANE STIFFE		OVERCL	A	FB60	X12	39.425659		0			YES
	20	48:	@PAN-FRA	MEFR3-6	5-STI-20	PLANE STIFFE			А	HP80	0X6	6.600157	1706.728159	3732.237243	4132.341592		YES
	20	482	2 @PAN-FRA	MEFR3-6	5-STI-21	PLANE STIFFE			А	HP80	0X6	6.6001	1706.728153	-3732.236171	4132.335889	0	YES
7 S	20	56	5 @PAN-FRA	MEFR9-7	7-PLA-17	PLANE PLATE	C	OVERCL	А	TH7.0	00	423.914939	4953.5	2187.680317	4000.213906	i (YES
8 5	20	57	7 @PAN-FRA	MEFR9-7	7-PLA-18	PLANE PLATE	C	OVERCL	А	TH10	0.00	704.609397	4955	-5.611629	2458.017643	0	YES
9 5	20	58	B @PAN-FRA	MEFR9-7	7-PLA-21	PLANE PLATE	S	в	Α	TH7.0	00	339.219561	4953.5	-2861.977212	3968.136641	. 0	YES
10 5	20	458	@PAN-FRA	MEFR9-7	7-STI-25	PLANE STIFFE	NER P	PS	А	FB60	X10	5.880671	4919.806998	3976.459153	2866.213783	c c	YES
11 5	20	459	@PAN-FRA	MEFR9-7	7-STI-28	PLANE STIFFE	NER S	в	А	FB60	X10	5.880671	4919.806998	-3976.459103	2866.213782		YES
12 5	20	460	@PAN-FRA	MEFR9-7	7-STI-31	PLANE STIFFE	NER P	PS	А	HP16	50X8	26.493209	5052.897774	4323.067455	3523.453381		YES
13 5	20	46:	e @PAN-FRA	MEFR9-7	7-STI-34	PLANE STIFFE	NER P	s	A	HP16	50X8	24.132458	5052.693083	3843.391493	3651.730772		YES
L4 S	20	462	2 @PAN-FRA	MEFR9-7	7-STI-37	PLANE STIFFE	NER P	s	A	HP16	50X8	24.443871	5054.988099	3293.24842	3674.18125	C	YES
15 5	20	463	@PAN-FRA	MEFR9-7	7-STI-40	PLANE STIFFE	NER P	s	А	HP10	00X7	14.151687	5018.68072	1644.538035	3671.729	0	YES
16 5	20	464	a @PAN-FRA	MEFR9-7	7-STI-43	PLANE STIFFE	NER P	s	А	HP10	0X7	12.747914	5017.817429	1094.601325	3645.896085	C	YES
L7 S	20	465	6 @PAN-FRA	MEFR9-7	7-STI-50	PLANE STIFFE	NER S	в	A	HP16	50X8	24.132458	5052.693083	-3843.391493	3651.730772		YES
8 5	20	460	6 @PAN-FRA	MEFR9-7	7-STI-51	PLANE STIFFE	NER S	в	А	HP16	50X8	24.443871	5054.988099	-3293.24842	3674.18125		YES
.9 S	20	46	7 @PAN-FRA	MEFR9-7	7-STI-52	PLANE STIFFE	NER S	в	A	HP10	0X7	14.151687	5018.68072	-1644.538035	3671.729	0	YES
20 5	20	468	- B @PAN-FRA	MEFR9-7	7-STI-53	PLANE STIFFE	NER S	в	A	HP10	0X7	13.277534	5018.680671	-1094.538039	3608.00175		YES
21 5	20		-			PLANE STIFFE		B	A	HP16	50X8	26.493209	5052.897774	-4323.067455	3523.453381		YES
22 5			@PAN-FRA			PLANE STIFFE		B	A	HP10		12.84928					YES
23 5			-			PLANE STIFFE		s	A	FB60			4919.430743	810.002054			YES
4 5			-			PLANE STIFFE		B	A	FB60			4919.430743	-810.001246			YES
	20		@PAN-FRA			PLANE STIFFE		s	A	FB60		5.413412		2205			YES
26 5			-			PLANE STIFFE		B	A	FB60			4988.994724	-2205			YES
27 5			-			PLANE STIFFE		s	A	HP10			5016.024186	2200			YES
	20		5 @PAN-FRA						A	HP10		7.490183		-2200			YES
	20		-			PLANE STIFFE		OVERCL		HP80			5005.095413	548,999634			YES
30 5			-			PLANE STIFFE			A	HP10			5015.976418	2194.52603			YES
31 5			@PAN-FRA			PLANE STIFFE			A	HP10		4.333578					YES
32 5			@PAN-LON			PLANE PLATE		OVERCL		TH10		120.726569	948.055669	-2134.32003			YES
33 5			@PAN-LON			PLANE STIFFE		OVERCL		FB60			1250.836391	33.67029			YES
34 5			@PAN-LON			PLANE STIFFE		OVERCL		FB60		7.120355	825.086273	34.419622			YES
35 S			a @PAN-LON			PLANE STIFFE		OVERCL		FB60		6.085013	1555		3994.115958		YES
10 3	20	424	+ @PAN-LON	03-8-51	1-25	PLANE STIFFE	INCK U	DVERCL	A	FB00.	X10	0.085013	1222	55.243972	3554.113938	, i	1153


Part list example




Pipe modeling example 1




Pipe modeling example 2




Component catalog example



Standard component definitions



Pipe spool example



Pipe line isometrics

😱 🖬 🤊 - 🛛 -	a					S22_	outfitting_re	port.csv - M	icrosoft Exce	1								. 0 🗾
Home Inse	ert Page Layout	Formulas Da	ita Review	Viev	v Devel	oper											(0 - 🗖
📇 🐰 Cut	le mai	44 (8 [±] ¥)		~			c			2		-		Σ AutoSu	m • A	44		
Copy	Calibri		= = =	**/	Wrap Te	ext	General	*	<u></u>		±	<u> </u>		😺 Fill 👻	Zĭ			
Paste J Format Paint	ter B I U ·	🔤 - 🔕 - <u>A</u> -	토 폰 폰	律律	📑 Merge	& Center 👻	\$ - %	• • • • • • • • • • • • • • • • • • •		al Format a ∗as Table •	Cell Styles x	Insert Dele	te Format	Q Clear ▼		Find & Select *		
Clipboard	Fa Fon	it Gi		Alignm	ient	6	Numb	er 5	ronnatting	Styles	Styles	Cell	s	-	Editing	Jerece		
H9	• (f _x	······											· ,	с				
A B	C D	E	F	G	HIJ		L	M	N	0	P	Q	R	S	T	U	V	W
In ModuleName	· ·	PartName	Type	Side	IVI DI D	e Surface	Mass		COG.x		COG.z		Assembly	ArticleCoo		Attribute	Attribute	Attribut
2 # S22	310	310-L0024	PIPE LINE					0.004789		3856.902					YES			
3 # S22 4 # S22	310	310-L0024-1 310-L0024-2	PIPE LINE	PS PS		0.326248		0.003291 0.003316	14949	3512.917					YES			
4 # S22 5 # S22	310 310	310-L0024-2 310-L0024-3	PIPE LINE	PS		0.331248				3631.748 4063.06					YES YES			
			PIPE LINE			0.320626												
5 # S22 7 # S22	310 310	310-L0013 310-L0022	PIPE LINE PIPE LINE	PS PS				0.006247		3880.85 3856.902	2230.65				YES			
															YES			
	310	310-L0023	PIPE LINE	PS		0.367669												
9 # S22 0 # S22	310 310	310-L0015 310-L0018	PIPE LINE PIPE LINE	PS PS	L	0.494992				3880.082 3865.902					YES			
0 # S22 1 # S22				PS											YES			
1 # S22 2 # S22	310 310	310-L0018-1 310-L0018-3	PIPE LINE PIPE LINE	PS		0.091541	5.342	0.001312		3856.938					YES			
2 # S22 3 # S22	310	310-L0018-3	PIPE LINE PIPE LINE	PS		0.091541									YES			
3 # 522 4 # \$22	310	310-L0019 310-L0022-2	PIPE LINE PIPE LINE	PS		0.331248				4220.752 3631.748					YES			
4 # S22 5 # S22	310	310-L0022-2 310-L023	PIPE LINE PIPE LINE	PS		0.331248				3631.748					YES			
5 # S22 6 # S22	310	310-L023 310-L0013-1	PIPE LINE PIPE LINE	PS		0.425881									YES			
	310			PS				0.000943		3765.288								
7 # S22 8 # S22	310	310-L0015-1 310-L023-3	PIPE LINE PIPE LINE	PS			3.666678								YES YES			
9 # S22	310			PS		0.045034				3653.245					YES			
20 # S22	310	310-L023-4 310-L0022-3	PIPE LINE PIPE LINE	PS			13.39814			4062.532					YES			
1 # S22	310	310-L0022-3 310-L0027	PIPE LINE PIPE LINE	PS			14.22515		14545.57						YES			
1 # 522 2 # \$22	310	310-L0027		PS				0.00391		4065.851					YES			
2 # 522 3 # 522	310	310-L0027-1 310-L0023-2	PIPE LINE	PS											YES			
24 # S22	310	310-L0023-2 310-L023-5	PIPE LINE PIPE LINE	PS		0.044083				3607.391					YES			
24 # 522 25 # S22	310	310-L023-5 310-L023-6		PS		0.106343				3607.391					YES			
5 # S22	310	310-L023-0 310-L023-7	PIPE LINE PIPE LINE	PS		0.106343				3607.391					YES			
20 # 522 27 # 522	310	310-L023-7 310-L023-8	PIPE LINE PIPE LINE	PS				0.000999		3607.391					YES			
27 # 522 28 # 522	310	310-L023-8 310-L0013-2	PIPE LINE PIPE LINE	PS		0.106343		0.000999		3856.902					YES			
9 # S22	310	310-L0015-2	PIPE LINE PIPE LINE			0.292423									YES			
0 # S22	310	310-L0013-2 310-L0014	PIPE LINE PIPE LINE	PS		0.335822				3856.902					YES			
1 # S22	310	310-L0014 310-L0014-3		PS		0.335822									YES			
2 # S22	310	310-L0014-3	PIPELINE	PS		0.302533				4131.843					YES			
3 # S22	310	310-L0014-4 310-L0014-5		PS		0.302533									YES			
4 # S22	310	310-L0014-5 310-L0014-6		PS		0.302533				4131.802					YES			
5 # S22	310	310-L0014-0 310-L0014-7	PIPELINE	PS		0.302533									YES			
6 # S22	310	310-L0014-7 310-L0014-8	PIPE LINE PIPE LINE	PS		0.098229					1000.301				YES			
7 # S22	310	310-L0013-6	PIPE LINE	PS		0.038223									YES			
37 # 322 38 # \$22	310	310-L0015-3		PS		0.456213									YES			
9 # S22	310	310-L0002		PS		0.381491		0.005199			1206.144				YES			
40 # S22	310	310-L0002 310-L0007	PIPELINE	PS		2.216267									YES			
+0 # 522 +1 # S22	310	310-L0007 310-L0027-1-1	PIPE LINE PIPE LINE			0.057593		0.000603							YES			
+		510-2002/-1-1	PIPELINE	-3		0.007395	3.6333	0.000005	10720.75	4085.751	2721.211				123			
eady	report / U															100%	0	

Outfitting part list example



SoftCAD Solutions s.r.l

SOFTWARE PARK 23.Portului Street Galati,Romania Mobile : 0745657447 E-mail: softcad@softwarepark-galati.ro http://www.softcadsolutions.shorturl.com/